



Waste & Overflow— Rough-In Kit & Trim Kit

Specifications:

- 2 Hole Bath Waste and Overflow w/1-hole converter bar
- Test Kit
- Zinc strainer



A = 1-1/2" Schedule 40 DWV
 B = 2-7/8"

Qty	Product Code	Description/Finish	Model #	Case/Qty
	60250	2-hole Rough-in w/test, PVC, CP	ABA1335RIZTB	20



Specifications:

- 1 Hole Overflow Plate w/screw
- Brass Turn Top Stopper

Qty	Product Code	Description/Finish	Model #	Case/Qty
	62250	1-hole Trim Kit w/zinc stopper, CP	ABA1310TK	20

